


D-1200 SERIES DISPLAY Wiring Diagram



WARNINGS:

1. This diagram is for use only for D-1201 or D-1202 Display Modules powered by 24 VAC.
2. The analog 4-20 mA output from the FT-3400 flow meter is active. Do not connect any other power source.