




System-1000 and FT-3400 Wiring Diagram CHANNEL 1



KEY NOTES:

1. PROVIDE A CLASS II POWER SUPPLY WITH SUFFICIENT POWER FOR THE DISPLAY AND FLOW METER
2. SYSTEM-1000 CAN POWER UP TO A TOTAL OF 1AMP FOR THE COMBINED CURRENT OF ALL THE ATTACHED DEVICES. SYS-1000 CAN POWER UP TO TWO FT-3400. ON 24V SYS-1000 USE TERMINAL J14 AND J15 TO POWER OTHER AC/DC DEVICES.
3. REFER TO IOM WIRING DIAGRAM FOR ADDITIONAL WIRING INFORMATION ON OTHER ONICON FLOW METERS



System-1000 and FT-3400 Wiring Diagram CHANNEL 2

